

What's in the box?

We provide:

- □ (1) BoilerScope[™]
- □ (4) Mounting screws
- □ (1) 24VDC power supply
- □ (1) 3-foot Ethernet cable
- □ (1-4) adapters, depending on the number of boilers to be monitored
- Installation Instructions

What do you provide?

- Cable:
 - Minimum: Three-wire cable (at least 24 AWG) to connect the BoilerScope™ to a boiler and the boilers to one another.
 - <u>Ideal</u> (especially in areas with electrical noise): Cable with at least one twisted pair and one ground. Cat5 cable works just fine. There are more than enough wires, but the cable may be handy.
- Small Phillips and flat-head screwdrivers.
- Wire strippers.
- A boiler or two...

